






Remove crane flask (8) from housing door.

Move selector switch (9) from  to 

Switches for change of direction of the windsifter (10):

forward 

backward 

right 

left 